

Land Cruiser 200

Corrections to Repair Manual RM22W1E


Please ensure these pages are distributed to all relevant staff for their information; and a copy made available for future reference, with the above repair manual.

Section	Title	Paragraph
1VD-FTV ENGINE CONTROL	ECD SYSTEM (w/o DPF)	P0046 (2013/01 - 2013/08)
		P0046 (2013/08 -)
		P00AF (2013/01 - 2013/08)
		P00AF (2013/08 -)
		P1258 (2013/01 - 2013/08)
		P1258 (2013/08 -)

The revised pages listed above are attached.
(The corrected parts are indicated by arrows.)

This Bulletin does not cause the Flat Rate Manual to be changed.

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)



P0046, P004B

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
Ignition switch ON for 5 seconds	Either of the following conditions are met when the motor is driving (1 trip detection logic): - DC motor duty ratio is +/-100% for 1.3 seconds or more. - DC motor current is 2.2 A or more for 5 seconds or more.	- Open or short in DC motor (turbocharger sub-assembly) circuit - Turbo motor driver - DC motor (turbocharger sub-assembly) - Turbocharger nozzle vane is stuck or movement is irregular

P0047, P004C

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
Ignition switch ON for 1 second	Both of following conditions are met for 1 second or more when the motor is driving (1 trip detection logic): - DC motor duty ratio is 100%. - DC motor current is 0.5 A or less.	- Open in DC motor (turbocharger sub-assembly) circuit - Turbo motor driver - DC Motor (turbocharger sub-assembly) - Turbocharger nozzle vane is stuck or movement is irregular

P0048, P004D

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
Ignition switch ON for 1 second	DC motor current is 6.5 A or more for 0.5 seconds or more when the motor is operating (1 trip detection logic).	- Short in DC motor (turbocharger sub-assembly) circuit - Turbo motor driver - DC Motor (turbocharger sub-assembly) - Turbocharger nozzle vane is stuck or movement is irregular

HINT:

If DTC P0046, P0047, P0048, P004B, P004C and/or P004D is stored, the following symptoms may appear.


Stuck closed malfunction:

- Vehicle surge when driving with full load

Stuck open malfunction:

- Lack of power
- Vehicle surge or hesitation under light or medium load
- White smoke

[Corrected]


**WIRING DIAGRAM****INSPECTION PROCEDURE****HINT:**

Read freeze frame data using the intelligent tester. Freeze frame data records the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, and other data from the time the malfunction occurred.

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

1 INSPECT TURBOCHARGER SUB-ASSEMBLY (DC MOTOR) (for Bank 1 or Bank 2)

Component without harness connected:
(DC Motor)



A182376E01

OK

- (a) Disconnect the DC motor connector.
(b) Measure the resistance according to the value(s) in the table below.

**Standard Resistance
for Bank 1**

Tester Connection	Condition	Specified Condition
1 (M-) - 2 (M+)	Always	1 to 100 Ω

**Standard Resistance
for Bank 2**

Tester Connection	Condition	Specified Condition
1 (M2-) - 2 (M2+)	Always	1 to 100 Ω

NG


Go to step 6

ES


2 CHECK HARNESS AND CONNECTOR (DC MOTOR - TURBO MOTOR DRIVER)

- (a) Disconnect the DC motor (for Bank 1) connector.
(b) Disconnect the DC motor (for Bank 2) connector.
(c) Disconnect the turbo motor driver connector.

Front view of wire harness connector:
(to Turbo Motor Driver)



Front view of wire harness connector:
(to DC Motor (for Bank 1))



*1: Bank 1

*2: Bank 2

A325136E01

- (d) Measure the resistance according to the value(s) in the table below.

**Standard Resistance (Check for Open)
for Bank 1**

Tester Connection	Condition	Specified Condition
C90-1 (M-) - A48-10 (M-)	Always	Below 1 Ω
C90-2 (M+) - A48-3 (M+)	Always	Below 1 Ω

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

for Bank 2

Tester Connection	Condition	Specified Condition
z67-1 (M2-) - A48-19 (M2-)	Always	Below 1 Ω
z67-2 (M2+) - A48-18 (M2+)	Always	Below 1 Ω

Standard Resistance (Check for Short)

for Bank 1

Tester Connection	Condition	Specified Condition
C90-1 (M-) or A48-10 (M-) - Body ground	Always	10 k Ω or higher
C90-2 (M+) or A48-3 (M+) - Body ground	Always	10 k Ω or higher

for Bank 2

Tester Connection	Condition	Specified Condition
z67-1 (M2-) or A48-19 (M2-) - Body ground	Always	10 k Ω or higher
z67-2 (M2+) or A48-18 (M2+) - Body ground	Always	10 k Ω or higher

ES

NG

Go to step 7

OK

3 INSPECT TURBOCHARGER SUB-ASSEMBLY

- Connect the intelligent tester to the DLC3.
- Turn the ignition switch to ON and turn the tester on.
- Start the engine and warm up.
- Move the shift lever to 3rd and accelerate the vehicle with the accelerator fully open.
- Stop the vehicle.
- Enter the following menus: Powertrain / Engine / DTC.
- Read the DTCs.


Result

Display (DTC Output)	Proceed to
DTC P0046, P0047, P0048, P004B, P004C and/or P004D are output	A
No DTC output	B

HINT:

- A snapshot can be used to compare vehicle data from the time of the malfunction to normal data and is very useful for troubleshooting.
- "Target Booster Pressure" and "MAP" in the snapshot can be used to check the operation of the turbocharger. If "MAP" does not follow "Target Booster Pressure", the turbocharger nozzle vane may be stuck or the movement may be irregular.
- When the engine speed is 2500 to 3000 rpm with the accelerator pedal fully depressed, "MAP" is within +/- 10 kPa* of "Target Booster Pressure" (not immediately after beginning of acceleration).
- * If the turbocharger pressure does not reach a specified value, it cannot be determined whether the system is normal by checking whether "MAP" is within +/-10 kPa of "Target Booster Pressure".

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)



HINT:

Compare "MAP" with "Target Booster Pressure" at the point indicated by the arrow (↑) in the illustration.

A

Go to step 6

B

4

INSPECT TURBO MOTOR DRIVER

- Connect the intelligent tester to the DLC3.
- Clear the DTCs (See page [See*](#)).
- Turn the engine switch off.
- Remove the rear fender splash shield sub-assembly RH.
- Remove the front fender liner LH.
- Disconnect the turbo motor driver connector.
- Reconnect the turbo motor driver connector.
- Turn the engine switch on (IG) and turn the tester on.
- After starting the engine, idle it for 5 seconds.
- Enter the following menus: Powertrain / Engine / DTC.
- Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

[See*: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR \(2013/01-2013/08\)](#)

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

B

END

A

5 REPLACE TURBO MOTOR DRIVER

- (a) Replace the turbo motor driver (See page
- [See*1](#)
-).

NOTICE:**Make sure that foreign matter does not enter the connector(s) when replacing parts.**

NEXT

Go to step 8

6 REPLACE TURBOCHARGER SUB-ASSEMBLY (for Bank 1 or Bank 2)

- (a) Replace the turbocharger sub-assembly (for Bank 1 or Bank 2) (See page
- [See*2](#)
-).

NEXT

Go to step 8

7 REPAIR OR REPLACE HARNESS OR CONNECTOR

NEXT

8 CONFIRM WHETHER MALFUNCTION HAS BEEN SUCCESSFULLY REPAIRED


- (a) Connect the intelligent tester to the DLC3.
- (b) Clear the DTCs (See page [See*3](#)).
- (c) Turn the ignition switch off.
- (d) Turn the ignition switch to ON for 5 seconds or more.
- (e) Enter the following menus: Powertrain / Engine / DTC.
- (f) Confirm that the DTC is not output again.

NEXT

END

[See*1: 1VD-FTV INTAKE / EXHAUST - TURBO MOTOR DRIVER - REMOVAL \(2013/01-2013/08\)](#)[See*2: 1VD-FTV INTAKE / EXHAUST - EXHAUST MANIFOLD W/ TURBOCHARGER - REMOVAL \(2013/01-2013/08\)](#)[See*3: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR \(2013/01-2013/08\)](#)

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)



A325132E02

P0046, P004B

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
Ignition switch ON for 5 seconds	Either of the following conditions are met when the motor is driving (1 trip detection logic): - DC motor duty ratio is +/-100% for 1.3 seconds or more. - DC motor current is 2.2 A or more for 5 seconds or more.	- Open or short in DC motor (turbocharger sub-assembly) circuit - Turbo motor driver - DC motor (turbocharger sub-assembly) - Turbocharger nozzle vane is stuck or movement is irregular

P0047, P004C

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
Ignition switch ON for 1 second	Both of following conditions are met for 1 second or more when the motor is driving (1 trip detection logic): - DC motor duty ratio is 100%. - DC motor current is 0.5 A or less.	- Open in DC motor (turbocharger sub-assembly) circuit - Turbo motor driver - DC Motor (turbocharger sub-assembly) - Turbocharger nozzle vane is stuck or movement is irregular

P0048, P004D

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
Ignition switch ON for 1 second	DC motor current is 6.5 A or more for 0.5 seconds or more when the motor is operating (1 trip detection logic).	- Short in DC motor (turbocharger sub-assembly) circuit - Turbo motor driver - DC Motor (turbocharger sub-assembly) - Turbocharger nozzle vane is stuck or movement is irregular

HINT:

If DTC P0046, P0047, P0048, P004B, P004C and/or P004D is stored, the following symptoms may appear.


Stuck closed malfunction:

- Vehicle surge when driving with full load

Stuck open malfunction:

- Lack of power
- Vehicle surge or hesitation under light or medium load
- White smoke

[Corrected]


**ES****WIRING DIAGRAM****INSPECTION PROCEDURE****HINT:**

Read freeze frame data using the intelligent tester. Freeze frame data records the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, and other data from the time the malfunction occurred.

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

1 INSPECT TURBOCHARGER SUB-ASSEMBLY (DC MOTOR) (for Bank 1 or Bank 2)

Component without harness connected:
(DC Motor)



A182376E01

- (a) Disconnect the DC motor connector.
(b) Measure the resistance according to the value(s) in the table below.

**Standard Resistance
for Bank 1**

Tester Connection	Condition	Specified Condition
1 (M-) - 2 (M+)	Always	1 to 100 Ω

**Standard Resistance
for Bank 2**

Tester Connection	Condition	Specified Condition
1 (M2-) - 2 (M2+)	Always	1 to 100 Ω

NG


Go to step 6

OK


2 CHECK HARNESS AND CONNECTOR (DC MOTOR - TURBO MOTOR DRIVER)

- (a) Disconnect the DC motor (for Bank 1) connector.
(b) Disconnect the DC motor (for Bank 2) connector.
(c) Disconnect the turbo motor driver connector.

Front view of wire harness connector:
(to Turbo Motor Driver)



Front view of wire harness connector:
(to DC Motor (for Bank 1))



*1: Bank 1

*2: Bank 2

A325136E01

- (d) Measure the resistance according to the value(s) in the table below.

**Standard Resistance (Check for Open)
for Bank 1**

Tester Connection	Condition	Specified Condition
C90-1 (M-) - A48-10 (M-)	Always	Below 1 Ω
C90-2 (M+) - A48-3 (M+)	Always	Below 1 Ω

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPf)

for Bank 2

Tester Connection	Condition	Specified Condition
z67-1 (M2-) - A48-19 (M2-)	Always	Below 1 Ω
z67-2 (M2+) - A48-18 (M2+)	Always	Below 1 Ω

Standard Resistance (Check for Short)

for Bank 1

Tester Connection	Condition	Specified Condition
C90-1 (M-) or A48-10 (M-) - Body ground	Always	10 k Ω or higher
C90-2 (M+) or A48-3 (M+) - Body ground	Always	10 k Ω or higher

for Bank 2

Tester Connection	Condition	Specified Condition
z67-1 (M2-) or A48-19 (M2-) - Body ground	Always	10 k Ω or higher
z67-2 (M2+) or A48-18 (M2+) - Body ground	Always	10 k Ω or higher

NG

Go to step 7

ES

OK

3

INSPECT TURBOCHARGER SUB - ASSEMBLY

- Connect the intelligent tester to the DLC3.
- Turn the ignition switch to ON and turn the tester on.
- Start the engine and warm up.
- Move the shift lever to 3rd and accelerate the vehicle with the accelerator fully open.
- Stop the vehicle.
- Enter the following menus: Powertrain / Engine / DTC.
- Read the DTCs.


Result

Display (DTC Output)	Proceed to
DTC P0046, P0047, P0048, P004B, P004C and/or P004D are output	A
No DTC output	B

HINT:

- A snapshot can be used to compare vehicle data from the time of the malfunction to normal data and is very useful for troubleshooting.
- "Target Booster Pressure" and "MAP" in the snapshot can be used to check the operation of the turbocharger. If "MAP" does not follow "Target Booster Pressure", the turbocharger nozzle vane may be stuck or the movement may be irregular.
- When the engine speed is 2500 to 3000 rpm with the accelerator pedal fully depressed, "MAP" is within +/- 10 kPa* of "Target Booster Pressure" (not immediately after beginning of acceleration).
- * If the turbocharger pressure does not reach a specified value, it cannot be determined whether the system is normal by checking whether "MAP" is within +/-10 kPa of "Target Booster Pressure".

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)



HINT:

Compare "MAP" with "Target Booster Pressure" at the point indicated by the arrow (↑) in the illustration.

A

Go to step 6

B

4

INSPECT TURBO MOTOR DRIVER


- Connect the intelligent tester to the DLC3.
- Clear the DTCs (See page [See*](#)).
- Turn the engine switch off.
- Remove the rear fender splash shield sub-assembly RH.
- Remove the front fender liner LH.
- Disconnect the turbo motor driver connector.
- Reconnect the turbo motor driver connector.
- Turn the engine switch on (IG) and turn the tester on.
- After starting the engine, idle it for 5 seconds.
- Enter the following menus: Powertrain / Engine / DTC.
- Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

[See*: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR \(2013/08-\)](#)

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)




[See*1: 1VD-FTV INTAKE / EXHAUST - TURBO MOTOR DRIVER - REMOVAL \(2013/08- \)](#)

[See*2: 1VD-FTV INTAKE / EXHAUST - EXHAUST MANIFOLD W/ TURBOCHARGER - REMOVAL \(2013/08- \)](#)

[See*3: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR \(2013/08- \)](#)

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)



P00AF

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
After idling for 5 seconds	When a communication error occurs between the turbo motor driver and ECM (1 trip detection logic).	• Turbo motor driver • Open or short in turbo motor driver circuit • Turbo motor driver ground problem • ECM


[Corrected]

P00B0

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
After idling for 5 seconds	When a communication error occurs between the turbo motor driver and ECM (1 trip detection logic).	• Turbo motor driver • Open or short in turbo motor driver circuit • Turbo motor driver ground problem • ECM

[Corrected]

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

- Read freeze frame data using the intelligent tester. Freeze frame data records the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.
- Excessive electrical noise, such as from wireless radios or electrical modifications, may cause a DTC to be stored.


NOTICE:

After replacing the ECM, the new ECM needs registration (See page ES-34) and initialization (See page ES-60).

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

1 INSPECT TURBO MOTOR DRIVER (POWER SOURCE CIRCUIT)

Front view of wire harness connector:
(to Turbo Motor Driver)



A325129E01

- (a) Disconnect the turbo motor driver connector.
(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage

Tester Connection	Condition	Specified Condition
A48-1 (+B) - A48-2 (GND)	Engine switch on (IG)	11 to 14 V
A48-16 (+B2) - A48-17 (GND2)	Engine switch on (IG)	11 to 14 V

- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance

Tester Connection	Condition	Specified Condition
A48-2 (GND) - Body ground	Always	Below 1 Ω
A48-17 (GND2) - Body ground	Always	Below 1 Ω

NG


Go to step 7

OK

2 CHECK HARNESS AND CONNECTOR (TURBO MOTOR DRIVER - ECM)

- (a) Disconnect the turbo motor driver connector.
(b) Disconnect the ECM connector.


Front view of wire harness connector:
(to ECM)



*1: for LHD

*2: for RHD

Front view of wire harness connector:
(to Turbo Motor Driver)



A325130E01

- (c) Measure the resistance according to the value(s) in the table below.

**Standard Resistance (Check for Open)
for LHD**

Tester Connection	Condition	Specified Condition
C45-49 (VNTI) - A48-5 (VNTI)	Always	Below 1 Ω
C45-50 (VNTI) - A48-4 (VNTI)	Always	Below 1 Ω

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPf)

Tester Connection	Condition	Specified Condition
C45-47 (VNO2) - A48-20 (VNO2)	Always	Below 1 Ω
C45-48 (VNI2) - A48-11 (VNI2)	Always	Below 1 Ω

for RHD

Tester Connection	Condition	Specified Condition
C46-49 (VNT0) - A48-5 (VNT0)	Always	Below 1 Ω
C46-50 (VNTI) - A48-4 (VNTI)	Always	Below 1 Ω
C46-47 (VNO2) - A48-20 (VNO2)	Always	Below 1 Ω
C46-48 (VNI2) - A48-11 (VNI2)	Always	Below 1 Ω

Standard Resistance (Check for Short)

for LHD

Tester Connection	Condition	Specified Condition
C45-49 (VNT0) or A48-5 (VNT0) - Body ground	Always	10 k Ω or higher
C45-50 (VNTI) or A48-4 (VNTI) - Body ground	Always	10 k Ω or higher
C45-47 (VNO2) or A48-20 (VNO2) - Body ground	Always	10 k Ω or higher
C45-48 (VNI2) or A48-11 (VNI2) - Body ground	Always	10 k Ω or higher

for RHD

Tester Connection	Condition	Specified Condition
C46-49 (VNT0) or A48-5 (VNT0) - Body ground	Always	10 k Ω or higher
C46-50 (VNTI) or A48-4 (VNTI) - Body ground	Always	10 k Ω or higher
C46-47 (VNO2) or A48-20 (VNO2) - Body ground	Always	10 k Ω or higher
C46-48 (VNI2) or A48-11 (VNI2) - Body ground	Always	10 k Ω or higher

NG

Go to step 8

OK

3 INSPECT TURBO MOTOR DRIVER (for Bank 1 and Bank 2)

See*: 1VD-FTV ENGINE CONTROL -
ECD SYSTEM - DTC CHECK / CLEAR
(2013/01-2013/08)

- Connect the intelligent tester to the DLC3.
- Clear the DTCs (See page [See*](#)).
- Turn the engine switch off.
- Remove the rear fender splash shield sub-assembly RH.
- Remove the front fender liner LH.
- Disconnect the turbo motor driver connector.
- Reconnect the turbo motor driver connector.
- Turn the engine switch on (IG) and turn the tester on.
- After starting the engine, idle it for 5 seconds.
- Enter the following menus: Powertrain / Engine / DTC.
- Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

B

END

A

4

REPLACE TURBO MOTOR DRIVER

- (a) Replace the turbo motor driver (See page [See*1](#)).

NOTICE:

Make sure that foreign matter does not enter the connector(s) when replacing parts.

NEXT

5

CHECK WHETHER DTC OUTPUT RECURS

See*1: 1VD-FTV INTAKE / EXHAUST - TURBO MOTOR DRIVER - REMOVAL (2013/01-2013/08)
 See*2: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR (2013/01-2013/08)
 See*3: 1VD-FTV ENGINE CONTROL - ECM - REMOVAL (2013/01-2013/08)

- (a) Connect the intelligent tester to the DLC3.
 (b) Clear the DTCs (See page [See*2](#)).
 (c) Turn the engine switch off.
 (d) Turn the engine switch on (IG) and turn the tester on.
 (e) After starting the engine, idle it for 5 seconds.
 (f) Enter the following menus: Powertrain / Engine / DTC.
 (g) Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

B

END

A

6

REPLACE ECM

- (a) Replace the ECM (See page [See*3](#)).

NEXT

Go to step 9

7

REPAIR OR REPLACE HARNESS OR CONNECTOR (POWER SOURCE CIRCUIT)

NEXT

Go to step 9

8

REPAIR OR REPLACE HARNESS OR CONNECTOR (TURBO MOTOR DRIVER - ECM)

NEXT

9

CONFIRM WHETHER MALFUNCTION HAS BEEN SUCCESSFULLY REPAIRED

- (a) Connect the intelligent tester to the DLC3.

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

- (b) Clear the DTCs (See page [See*](#)).
- (c) Turn the ignition switch off.
- (d) After starting the engine, idle it for 5 seconds.
- (e) Enter the following menus: Powertrain / Engine / DTC.
- (f) Confirm that the DTC is not output again.


NEXT

[See*: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR \(2013/01-2013/08\)](#)

END

ES

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)



P00AF

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
After idling for 5 seconds	When a communication error occurs between the turbo motor driver and ECM (1 trip detection logic).	- Turbo motor driver - Open or short in turbo motor driver circuit - Turbo motor driver ground problem - ECM


[Corrected]

P00B0

DTC Detection Drive Pattern	DTC Detection Condition	Trouble Area
After idling for 5 seconds	When a communication error occurs between the turbo motor driver and ECM (1 trip detection logic).	- Turbo motor driver - Open or short in turbo motor driver circuit - Turbo motor driver ground problem - ECM

[Corrected]

WIRING DIAGRAM



ES

INSPECTION PROCEDURE

HINT:

- Read freeze frame data using the intelligent tester. Freeze frame data records the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.
- Excessive electrical noise, such as from wireless radios or electrical modifications, may cause a DTC to be stored.


NOTICE:

After replacing the ECM, the new ECM needs registration (See page ES-47) and initialization (See page ES-60).

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

1 INSPECT TURBO MOTOR DRIVER (POWER SOURCE CIRCUIT)

Front view of wire harness connector:
(to Turbo Motor Driver)



- (a) Disconnect the turbo motor driver connector.
(b) Measure the voltage according to the value(s) in the table below.

Standard Voltage

Tester Connection	Condition	Specified Condition
A48-1 (+B) - A48-2 (GND)	Engine switch on (IG)	11 to 14 V
A48-16 (+B2) - A48-17 (GND2)	Engine switch on (IG)	11 to 14 V

- (c) Measure the resistance according to the value(s) in the table below.

Standard Resistance

Tester Connection	Condition	Specified Condition
A48-2 (GND) - Body ground	Always	Below 1 Ω
A48-17 (GND2) - Body ground	Always	Below 1 Ω

NG


Go to step 7

OK


2 CHECK HARNESS AND CONNECTOR (TURBO MOTOR DRIVER - ECM)

- (a) Disconnect the turbo motor driver connector.
(b) Disconnect the ECM connector.

Front view of wire harness connector:
(to ECM)



Front view of wire harness connector:
(to Turbo Motor Driver)



*1: for LHD

*2: for RHD

- (c) Measure the resistance according to the value(s) in the table below.

**Standard Resistance (Check for Open)
for LHD**

Tester Connection	Condition	Specified Condition
C45-49 (VNTI) - A48-5 (VNTI)	Always	Below 1 Ω
C45-50 (VNTI) - A48-4 (VNTI)	Always	Below 1 Ω

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

Tester Connection	Condition	Specified Condition
C45-47 (VNO2) - A48-20 (VNO2)	Always	Below 1 Ω
C45-48 (VNI2) - A48-11 (VNI2)	Always	Below 1 Ω

for RHD

Tester Connection	Condition	Specified Condition
C46-49 (VNT0) - A48-5 (VNT0)	Always	Below 1 Ω
C46-50 (VNTI) - A48-4 (VNTI)	Always	Below 1 Ω
C46-47 (VNO2) - A48-20 (VNO2)	Always	Below 1 Ω
C46-48 (VNI2) - A48-11 (VNI2)	Always	Below 1 Ω

Standard Resistance (Check for Short)

for LHD

Tester Connection	Condition	Specified Condition
C45-49 (VNT0) or A48-5 (VNT0) - Body ground	Always	10 k Ω or higher
C45-50 (VNTI) or A48-4 (VNTI) - Body ground	Always	10 k Ω or higher
C45-47 (VNO2) or A48-20 (VNO2) - Body ground	Always	10 k Ω or higher
C45-48 (VNI2) or A48-11 (VNI2) - Body ground	Always	10 k Ω or higher

for RHD

Tester Connection	Condition	Specified Condition
C46-49 (VNT0) or A48-5 (VNT0) - Body ground	Always	10 k Ω or higher
C46-50 (VNTI) or A48-4 (VNTI) - Body ground	Always	10 k Ω or higher
C46-47 (VNO2) or A48-20 (VNO2) - Body ground	Always	10 k Ω or higher
C46-48 (VNI2) or A48-11 (VNI2) - Body ground	Always	10 k Ω or higher

NG

Go to step 8

OK

3

INSPECT TURBO MOTOR DRIVER (for Bank 1 and Bank 2)

See*: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR (2013/08-)

- Connect the intelligent tester to the DLC3.
- Clear the DTCs (See page [See*](#)).
- Turn the engine switch off.
- Remove the rear fender splash shield sub-assembly RH.
- Remove the front fender liner LH.
- Disconnect the turbo motor driver connector.
- Reconnect the turbo motor driver connector.
- Turn the engine switch on (IG) and turn the tester on.
- After starting the engine, idle it for 5 seconds.
- Enter the following menus: Powertrain / Engine / DTC.
- Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

B

END

A

4

REPLACE TURBO MOTOR DRIVER

- (a) Replace the turbo motor driver (See page [See*1](#)).

NOTICE:

Make sure that foreign matter does not enter the connector(s) when replacing parts.

NEXT

5

CHECK WHETHER DTC OUTPUT RECURS

- (a) Connect the intelligent tester to the DLC3.
 (b) Clear the DTCs (See page [See*2](#)).
 (c) Turn the engine switch off.
 (d) Turn the engine switch on (IG) and turn the tester on.
 (e) After starting the engine, idle it for 5 seconds.
 (f) Enter the following menus: Powertrain / Engine / DTC.
 (g) Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

B

END

A

6

REPLACE ECM

- (a) Replace the ECM (See page [See*3](#)).

NEXT

Go to step 9

7

REPAIR OR REPLACE HARNESS OR CONNECTOR (POWER SOURCE CIRCUIT)

NEXT

Go to step 9

8

REPAIR OR REPLACE HARNESS OR CONNECTOR (TURBO MOTOR DRIVER - ECM)

NEXT

9

CONFIRM WHETHER MALFUNCTION HAS BEEN SUCCESSFULLY REPAIRED

- (a) Connect the intelligent tester to the DLC3.


See*1: 1VD-FTV INTAKE / EXHAUST - TURBO MOTOR DRIVER - REMOVAL (2013/08-)
 See*2: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR (2013/08-)
 See*3: 1VD-FTV ENGINE CONTROL - ECM - REMOVAL (2013/08-)

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

- (b) Clear the DTCs (See page [See*](#)).
- (c) Turn the ignition switch off.
- (d) After starting the engine, idle it for 5 seconds.
- (e) Enter the following menus: Powertrain / Engine / DTC.
- (f) Confirm that the DTC is not output again.

NEXT[See*: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR \(2013/08- \)](#)**END****ES**

WIRING DIAGRAM




INSPECTION PROCEDURE

HINT:

Read freeze frame data using the intelligent tester. Freeze frame data records the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, and other data from the time the malfunction occurred.

1 | **CHECK HARNESS AND CONNECTOR (TURBO MOTOR DRIVER - NOZZLE VANE POSITION SENSOR)**

- Disconnect the nozzle vane position sensor (for Bank 1) connector.
- Disconnect the nozzle vane position sensor (for Bank 2) connector.
- Disconnect the turbo motor driver connector.



- (d) Measure the resistance according to the value(s) in the table below.

Standard Resistance (Check for Open) for Bank 1

Tester Connection	Condition	Specified Condition
A48-21 (VTAI) - C89-1 (VTA1)	Always	Below 1 Ω
A48-12 (VNE2) - C89-2 (VNE2)	Always	Below 1 Ω
A48-6 (VNVC) - C89-3 (VNVC)	Always	Below 1 Ω
A48-22 (VTA) - C89-4 (VTA)	Always	Below 1 Ω
A48-13 (E2S) - C89-5 (E2S)	Always	Below 1 Ω
A48-7 (VCS) - C89-6 (VCS)	Always	Below 1 Ω

for Bank 2

Tester Connection	Condition	Specified Condition
A48-23 (VTI2) - z66-1 (VTI2)	Always	Below 1 Ω
A48-14 (VE2) - z66-2 (VE2)	Always	Below 1 Ω
A48-8 (VNC2) - z66-3 (VNC2)	Always	Below 1 Ω
A48-24 (VTA2) - z66-4 (VTA2)	Always	Below 1 Ω
A48-15 (E2S2) - z66-5 (E2S2)	Always	Below 1 Ω
A48-9 (VCS2) - z66-6 (VCS2)	Always	Below 1 Ω

Standard Resistance (Check for Short) for Bank 1

Tester Connection	Condition	Specified Condition
A48-21 (VTA1) or C89-1 (VTA1) - Body ground	Always	10 kΩ or higher
A48-12 (VNE2) or C89-2 (VNE2) - Body ground	Always	10 kΩ or higher

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

Tester Connection	Condition	Specified Condition
A48-6 (VNVC) or C89-3 (VNVC) - Body ground	Always	10 kΩ or higher
A48-22 (VTA) or C89-4 (VTA) - Body ground	Always	10 kΩ or higher
A48-13 (E2S) or C89-5 (E2S) - Body ground	Always	10 kΩ or higher
A48-7 (VCS) or C89-6 (VCS) - Body ground	Always	10 kΩ or higher

for Bank 2

Tester Connection	Condition	Specified Condition
A48-23 (VTI2) or z66-1 (VTI2) - Body ground	Always	10 kΩ or higher
A48-14 (VE2) or z66-2 (VE2) - Body ground	Always	10 kΩ or higher
A48-8 (VNC2) or z66-3 (VNC2) - Body ground	Always	10 kΩ or higher
A48-24 (VTA2) or z66-4 (VTA2) - Body ground	Always	10 kΩ or higher
A48-15 (E2S2) or z66-5 (E2S2) - Body ground	Always	10 kΩ or higher
A48-9 (VCS2) or z66-6 (VCS2) - Body ground	Always	10 kΩ or higher

NG

Go to step 6

OK

2 INSPECT TURBO MOTOR DRIVER

- (a) Connect the intelligent tester to the DLC3.
- (b) Clear the DTCs (See page [See*1](#)).
- (c) Turn the engine switch off.
- (d) Remove the rear fender splash shield sub-assembly RH.
- (e) Remove the front fender liner LH.
- (f) Disconnect the turbo motor driver connector.
- (g) Reconnect the turbo motor driver connector.
- (h) Turn the engine switch on (IG) and turn the tester on.
- (i) After starting the engine, idle it for 5 seconds.
- (j) Enter the following menus: Powertrain / Engine / DTC.
- (k) Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

B

END

A

3 REPLACE TURBO MOTOR DRIVER

- (a) Replace the turbo motor driver (See page [See*2](#)).

NOTICE:

Make sure that foreign matter does not enter the connector(s) when replacing parts.

See*1: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR (2013/01-2013/08)
See*2: 1VD-FTV INTAKE / EXHAUST - TURBO MOTOR DRIVER - REMOVAL (2013/01-2013/08)

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPf)

NEXT

4 CHECK WHETHER DTC OUTPUT RECURS

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the engine switch on (IG) and turn the tester on.
- (c) Clear the DTCs (See page [See*1](#)).
- (d) Turn the engine switch off.
- (e) Turn the engine switch on (IG) and turn the tester on.
- (f) After starting the engine, idle it for 5 seconds.
- (g) Enter the following menus: Powertrain / Engine / DTC.
- (h) Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

B

END

A

5 REPLACE TURBOCHARGER SUB-ASSEMBLY (for Bank 1 or Bank 2) (NOZZLE VANE POSITION SENSOR)

- (a) Replace the turbocharger sub-assembly (for Bank 1 or Bank 2) (See page [See*2](#)).

NEXT

Go to step 7

6 REPAIR OR REPLACE HARNESS OR CONNECTOR

NEXT

7 CONFIRM WHETHER MALFUNCTION HAS BEEN SUCCESSFULLY REPAIRED

- (a) Connect the intelligent tester to the DLC3.
- (b) Clear the DTCs (See page [See*1](#)).
- (c) Turn the ignition switch off.
- (d) Turn the ignition switch off and leave the vehicle for 15 seconds.
- (e) Turn the ignition switch to ON for 1 second.
- (f) Confirm that the DTC is not output again.

HINT:

Perform the following procedure using the tester to determine whether or not the DTC judgment has been carried out

- (1) Enter the following menus: Powertrain / Engine / Utility / All Readiness.
- (2) Input DTC P1258, P1259, P1260, P1262, P1263, P2563, P2564, P2565, P2588 and/or P2589.

See*1: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR (2013/01-2013/08)
 See*2: 1VD-FTV INTAKE / EXHAUST - EXHAUST MANIFOLD W/ TURBOCHARGER - REMOVAL (2013/01-2013/08)

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)


- (3) Check that STATUS is NORMAL. If STATUS is INCOMPLETE or UNKNOWN, idle the engine.

NEXT

END

ES

WIRING DIAGRAM



INSPECTION PROCEDURE



HINT:

Read freeze frame data using the intelligent tester. Freeze frame data records the engine condition when malfunctions are detected. When troubleshooting, freeze frame data can help determine if the vehicle was moving or stationary, if the engine was warmed up or not, and other data from the time the malfunction occurred.

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

1**CHECK HARNESS AND CONNECTOR (TURBO MOTOR DRIVER - NOZZLE VANE POSITION SENSOR)**

- (a) Disconnect the nozzle vane position sensor (for Bank 1) connector.
- (b) Disconnect the nozzle vane position sensor (for Bank 2) connector.
- (c) Disconnect the turbo motor driver connector.

Front view of wire harness connector:
(to Turbo Motor Driver)Front view of wire harness connector:
(to Nozzle Vane Position Sensor)

*1: Bank 1
*2: Bank 2

A325133E01

- (d) Measure the resistance according to the value(s) in the table below.

**Standard Resistance (Check for Open)
for Bank 1**

Tester Connection	Condition	Specified Condition
A48-21 (VTA1) - C89-1 (VTA1)	Always	Below 1 Ω
A48-12 (VNE2) - C89-2 (VNE2)	Always	Below 1 Ω
A48-6 (VNVC) - C89-3 (VNVC)	Always	Below 1 Ω
A48-22 (VTA) - C89-4 (VTA)	Always	Below 1 Ω
A48-13 (E2S) - C89-5 (E2S)	Always	Below 1 Ω
A48-7 (VCS) - C89-6 (VCS)	Always	Below 1 Ω

for Bank 2

Tester Connection	Condition	Specified Condition
A48-23 (VTI2) - z66-1 (VTI2)	Always	Below 1 Ω
A48-14 (VE2) - z66-2 (VE2)	Always	Below 1 Ω
A48-8 (VNC2) - z66-3 (VNC2)	Always	Below 1 Ω
A48-24 (VTA2) - z66-4 (VTA2)	Always	Below 1 Ω
A48-15 (E2S2) - z66-5 (E2S2)	Always	Below 1 Ω
A48-9 (VCS2) - z66-6 (VCS2)	Always	Below 1 Ω

**Standard Resistance (Check for Short)
for Bank 1**

Tester Connection	Condition	Specified Condition
A48-21 (VTA1) or C89-1 (VTA1) - Body ground	Always	10 k Ω or higher
A48-12 (VNE2) or C89-2 (VNE2) - Body ground	Always	10 k Ω or higher

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

Tester Connection	Condition	Specified Condition
A48-6 (VNVC) or C89-3 (VNVC) - Body ground	Always	10 kΩ or higher
A48-22 (VTA) or C89-4 (VTA) - Body ground	Always	10 kΩ or higher
A48-13 (E2S) or C89-5 (E2S) - Body ground	Always	10 kΩ or higher
A48-7 (VCS) or C89-6 (VCS) - Body ground	Always	10 kΩ or higher

for Bank 2

Tester Connection	Condition	Specified Condition
A48-23 (VTI2) or z66-1 (VTI2) - Body ground	Always	10 kΩ or higher
A48-14 (VE2) or z66-2 (VE2) - Body ground	Always	10 kΩ or higher
A48-8 (VNC2) or z66-3 (VNC2) - Body ground	Always	10 kΩ or higher
A48-24 (VTA2) or z66-4 (VTA2) - Body ground	Always	10 kΩ or higher
A48-15 (E2S2) or z66-5 (E2S2) - Body ground	Always	10 kΩ or higher
A48-9 (VCS2) or z66-6 (VCS2) - Body ground	Always	10 kΩ or higher

ES

NG

Go to step 6

OK

2 INSPECT TURBO MOTOR DRIVER

See*1: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR (2013/08-)
 See*2: 1VD-FTV INTAKE / EXHAUST - TURBO MOTOR DRIVER - REMOVAL (2013/08-)

- Connect the intelligent tester to the DLC3.
- Clear the DTCs (See page [See*1](#)).
- Turn the engine switch off.
- Remove the rear fender splash shield sub-assembly RH.
- Remove the front fender liner LH.
- Disconnect the turbo motor driver connector.
- Reconnect the turbo motor driver connector.
- Turn the engine switch on (IG) and turn the tester on.
- After starting the engine, idle it for 5 seconds.
- Enter the following menus: Powertrain / Engine / DTC.
- Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

B

END

A

3 REPLACE TURBO MOTOR DRIVER

- Replace the turbo motor driver (See page [See*2](#)).

NOTICE:

Make sure that foreign matter does not enter the connector(s) when replacing parts.

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPf)

NEXT

4 CHECK WHETHER DTC OUTPUT RECURS

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the engine switch on (IG) and turn the tester on.
- (c) Clear the DTCs (See page [See*1](#)).
- (d) Turn the engine switch off.
- (e) Turn the engine switch on (IG) and turn the tester on.
- (f) After starting the engine, idle it for 5 seconds.
- (g) Enter the following menus: Powertrain / Engine / DTC.
- (h) Read the DTCs.

Result

Display (DTC Output)	Proceed to
DTC is output	A
DTC is not output	B

B

END

A

5 REPLACE TURBOCHARGER SUB-ASSEMBLY (for Bank 1 or Bank 2) (NOZZLE VANE POSITION SENSOR)

- (a) Replace the turbocharger sub-assembly (for Bank 1 or Bank 2) (See page [See*2](#)).

NEXT

Go to step 7

6 REPAIR OR REPLACE HARNESS OR CONNECTOR

NEXT

7 CONFIRM WHETHER MALFUNCTION HAS BEEN SUCCESSFULLY REPAIRED

- (a) Connect the intelligent tester to the DLC3.
- (b) Clear the DTCs (See page [See*1](#)).
- (c) Turn the ignition switch off.
- (d) Turn the ignition switch off and leave the vehicle for 15 seconds.
- (e) Turn the ignition switch to ON for 1 second.
- (f) Confirm that the DTC is not output again.

HINT:

Perform the following procedure using the tester to determine whether or not the DTC judgment has been carried out

- (1) Enter the following menus: Powertrain / Engine / Utility / All Readiness.
- (2) Input DTC P1258, P1259, P1260, P1262, P1263, P2563, P2564, P2565, P2588 and/or P2589.

See*1: 1VD-FTV ENGINE CONTROL - ECD SYSTEM - DTC CHECK / CLEAR (2013/08-)

See*2: 1VD-FTV INTAKE / EXHAUST - EXHAUST MANIFOLD W/ TURBOCHARGER - REMOVAL (2013/08-)

1VD-FTV ENGINE CONTROL – ECD SYSTEM (w/o DPF)

- (3) Check that STATUS is NORMAL. If STATUS is INCOMPLETE or UNKNOWN, idle the engine.

NEXT

END

ES